

Programmable Digital Timer Instruction Manual

Thank you for your confidence in our product. We would like to ensure that you obtain the best possible result from your investment.

There is nothing for you to do except enjoy the increased security, energy savings and convenience it brings you.

CAUTION:

1. For installation must according to wire diagram. Please see the back of unit.
2. Press RESET button before use.
3. Recharge the battery when no indicate appear in the display.

BUTTONS INSTRUCTIONS:



- CLOCK (or 1)** : current time setting or show current time.
- TIMER (or 3)** : press this button to enter program mode. There are 8 on / 8 off programs.
- DAY (or 1...7)** : the day of the week setting button
- HOURL (or h +)** : hour setting button.
- MIN (or m +)** : minute setting button.
- MANUAL (or 1 AUTO 0)** : ON/AUTO/OFF select mode.
- ON** : RESET button to cancel all prior settings.
- LED lamp indicator**: LED light on when the device turn on.

TO SET PROGRAMS:

1. Press TIMER button "1 ON" will appear at the left side of display. This is the 1st program that you desire the device to turn on.
2. Press DAY button to select the program period. There are 15 settings for choice.

- (1) Mo. To Su. (2) Mo. (3) Tu. (4) We. (5) Th. (6) Fr. (7) Sa. (8) Su. (9) Mo. + Tu. + We. + Th. + Fr. (10) Sa. + Su. (11) Mo. + Tu. + We. + Th. + Fr. + Sa. (12) Mo. + We. + Fr. (13) Tu. + Th. + Sa. (14) Mo. + Tu. + We. (15) Th. + Fr. + Sa.

REVIEW YOUR PROGRAMS:

1. Press TIMER button to advance displayed to each subsequent on or off settings.
2. Check days and times displayed.
3. To make a change follow instruction's under "TO SET PROGRAMS".

MANUAL button:

1. Press MANUAL button to select ON/AUTO/OFF mode.

TO SET CURRENT TIME AND DAY:

1. Press CLOCK and DAY buttons until current day shows. Release both buttons for current day (today) setting.
2. Press CLOCK and HOUR buttons until current hour shows. Release both buttons for current hour (now) setting.
3. Press CLOCK and MIN buttons until current minute shows. Release both buttons for current day (now) setting.
4. After setting the weekday and time, the second will reset automatically.

2. On mode is to turn on the device. Off mode is to turn off the device.

3. Auto mode is to set the device to enter the programs. it will turn on or turn off according to the programs for which you settings

4. OVERRIDE FEATURE:

- Turn device on if already off or off if already on, timer automatically resumes program on next cycle.
- (From on to auto mode, it will turn on until next off program.)
- (From off to auto mode, it will turn off until next on program)